

SERVICE AND REPAIR PARTS

NEMA SIZE 5, SINGLE POLE, NORMALLY OPEN, P/N 59495 SERIES
NEMA SIZE 5A, SINGLE POLE, NORMALLY OPEN, P/N 59675 SERIES

INSTALLATION AND ADJUSTMENT

Mount the contactor vertically on a rigid support. Refer to Figure 1 for proper clearances above the top of the contactor, dimension A, and in front of the Arc Shield, dimension B, for arcing clearance, and Arc Shield removal. Check nameplate data for correct equipment. Check that the contactor operating coil (27) is the correct voltage. With all power removed, pivot the Arc Shield (11) upwards and operate the contactor by hand. The contact tips (15) should meet SQUARELY. If they do not, align them by the procedure in the Contact Tip Adjustment. Pivot the Arc Shield back to its proper position. **CAUTION: DO NOT OPERATE THE CONTACTOR UNDER LOAD UNLESS THE ARC SHIELD IS PIVOTED TO THE FULLY DOWN POSITION**




Fig. 1

ELECTRICAL CLEARANCES

Note: Shaded area for arcing clearances to ground, un-insulated enclosure or other control devices.

NEMA SIZES

DIM.	5	5A
A	6"	6 1/2"
B	4 3/8"	5"

CONTACTOR TIP ADJUSTMENT

1. With all power removed, pivot the arc shield (11) upward.
2. Check that the movable contact tip (15) is against the ledge located on the movable contact holder (17) (Fig. 2).
3. Make sure that the stationary contact tip (15) is against the ledge on the stationary support. (Fig. 2).
4. The contact tip surfaces must be aligned both vertically and horizontally (Fig. 2).
5. Pivot the Arc Shield back to its proper position.

WARNING: ALL METAL PARTS OF THE CONTACTOR MAY BE AT LINE VOLTAGE. ALL POWER MUST BE DISCONNECTED FROM THE CONTACTOR BEFORE PERFORMING ANY ADJUSTMENT, MAINTENANCE OR TROUBLE-SHOOTING PROCEDURES.

CAUTION: FAILURE TO CONNECT THE OPERATING COIL TO THE PROPER VOLTAGE MAY RESULT IN IMPROPER CONTACTOR OPERATION OR DAMAGE TO THE COIL.

CONTACTOR TIP REPLACEMENT

The contact tips should be replaced when the contacts are worn down to dimensions shown in Figure 2.

1. With all power removed, remove the Arc shield (11).
2. Remove the movable contact tip (15) by removing the Stainless Steel cap screw (39) and lockwasher (33) and arc horn (16) located on contact arm (17).
3. Remove the stationary contact tip by removing the Stainless Steel cap screw (52) and lock-washer (33) located on stationary contact support (12).

Fig. 2	CONTACTOR SIZE		A MATED DIMENSION	
			NEW	REPLACE
	5	N.O.	3/4"	3/8"
	5A	N.O.	3/4"	3/8"

4. Install the new stationary contact (15) tip using the new stainless steel screw (52) and lockwasher (33) provided.

5. Install the new movable contact tip (15) using the new Stainless Steel Screw (39, lockwasher (33), and arc horn (16) provided
6. Replace the contact spring (20) with the new spring provided.
7. Manually operate the contactor and check the contact tips for alignment. Align the contact tips to meet squarely.
8. Pivot the Arc Shield (11) back to its proper position.

AUXILIARY ELECTRICAL CONTACTS

1. With all power removed, check that auxiliary contact (60) has the proper follow-up travel by manually closing the contactor. With new auxiliary contacts, the correct operating height is as shown in Fig. 3.
2. If adjustment is needed bend the lower portion of the striker (56, 62).

The Auxiliary Electrical Contacts should be replaced when inspection of the contacts shows that they are burned or badly pitted. It is necessary that the entire auxiliary block be replaced as a unit.

1. With all power "OFF", loosen terminal screws and remove terminal leads. NOTE POSITION OF LEADS so they can be replaced properly.
2. Remove Contact Assembly by removing slotted screws (57).
3. Install NEW CONTACT ASSEMBLY as shown in the exploded view.
4. Manually operate the contactor and check the moving contacts for proper follow-up in Fig. 3.
5. Replace terminal leads.

OPERATING COIL REPLACEMENT

1. With all power removed, disconnect the coil leads.
2. Remove the armature bearing pin (22) by removing the hairpins (23).
3. Remove the armature/moving assembly (21)
4. Remove the screw (32) and lockwasher (38) on the front of the magnet core. Remove non-magnetic spacer (25), core cap (24) and coil (27).
5. Install the new coil using the core cap (24), non-magnetic spacer (25), and lockwasher (38) and tighten the screw (32). It is recommended that loctite thread lock be used on the core cap screw and that the screw is tightened to 200 in-lbs. Note that the steel core cap, which is thicker than the non-magnetic spacer, must be installed against the core. (See Exploded View).
6. Replace the armature and armature bearing pin (22) and hair pins (23).
7. Check that contact bearing pin (22) is centered and the hairpins (23) are secured.
8. Reconnect the coil leads.

SHUNT REPLACEMENT

The shunt (19) should be replaced when the flexible braided wires are broken or burned or if the wires are loose in the terminal connectors on either end of the shunt:

1. With all power removed, disconnect the bottom end of the shunt (19) by removing hex head screw (48), lockwasher (38), washer (43) and shunt from lower bus bar (30).

2. Disconnect the top end of the shunt by loosening the nut (41) then removing the screw (40) washer (37), lockwasher (33) and the shunt (19).
3. Install the new shunt. Spin the nut (40) to the bottom of the screw (41) head. Place the top end of the new shunt on the contact holder arm (17) and install by replacing the screw/ nut, lockwasher (33) and flat washer (37) as shown.
4. Check that the bearing pin (18) is centered and tighten the screw (41) very tight (120 in-lbs).
5. Hold the shunt ferrule straight in line with the vertical center line of the holder arm and Tighten the nut (41) to 135 in-lbs.
6. Connect the bottom end of the shunt (19) by replacing the washer (43), lockwasher (38), and hex head screw (48).

CAUTION: SHUNT MUST BE DIRECTLY AGAINST MOVABLE CONTACT HOLDER ARM (17) AT THE TOP END AND DIRECTLY AGAINST THE WIRE TERMINAL (30) AT THE BOTTOM END.

FAILURE TO FOLLOW THE STEPS ABOVE COULD CAUSE PREMATURE WEAR OF THE CONTACT HOLDER ARM IF SCREW (41) IS NOT TIGHT.





Fig. 3

PROPER OPERATED HEIGHT

the snap ring on plunger is even with bottom edge of cover opening

Item No.	Description	Part No.	Qty.		Item No.	Description	Part No.	Qty.	
			Size 5	Size 5A				Size 5	Size 5A
1	Mounting Pan	68038-000	1	1	40	Round Head Screw (5/16-18 x 1.5")	47241-218	1	1
2	Base	68022-001	1	1	41	Hex Nut (5/16-18)	47253-502	1	1
3	Arc Shield Retainer	81279-030	1	1	42	Hex Head Screw (3/8-16 x 1.25")	47246-104	4	4
4	Blowout Coil 250V	18493-000	1		43	Flat Washer (3/8")	47250-020	6	6
	Blowout Coil 550	19974-000	1		44	Hex Nut (3/8-16)	47253-503	4	4
	Blowout Coil 250V	41171-001		1	45	Hex Head Screw (3/8-16 x 1")	47246-103	1	1
	Blowout Coil 550	18493-000		1	46	Hex Head Screw (5/16-18 x 1")	47246-081	3	3
5	DC Blowout Core (Solid)	68870-035	1		47	Flat Washer (5/16")	47250-505	3	3
	AC Blowout Core (Slotted)	18599-000		1	48	Hex Head Screw (5/16-18 x 3.5")	47246-101	1	1
6	Blowout Insulating Tube	18601-000	1	1	49	Internal Lockwasher (5/16")	47304-010	1	1
7	Blowout Insulating Waster	18603-000	2	2	50	Hex Nut (5/16-18)	47253-602	2	2
8	Blowout Guard	68030-002	1	1	51	Hex Head Screw (5/16-18 x 0.75")	47246-079	1	1
9	Flux Plate Assembly LH	18061-000	1	1	52	Hex Head Screw SS (5/16-18 x 0.75")	47779-079	1	1
10	Flux Plate Assembly RH	18062-000	1	1	53	Flat Head Screw Brass (1/4-20 x 0.5")	47665-108	1	1
11	Arc Shield Assembly	59695-501	1	1	54	Auxiliary Contact Assembly Kit (items 55 thru 60)	68011-008	1	1
12	Stationary Contact Support	58718-002	1	1	55	Sems Screw (8-32 x 5/16")	47661-095	2	2
13	Spacer – Blowout Coil	18602-000	1	1	56	Auxiliary Striker	68029-001	1	1
14	Support Mounting Bracket	68023-000	1	1	57	Round Head Screw (8-32 x 2 1/16")	47241-261	2	2
15	Contact Tip (Copper)	18402-000	2	2	58	Lock Washer (No. 8)	47252-006	2	2
	Contact Tip (Silver)	18402-001	2	2	59	Screw Insulating Sleeve	73108-000	2	2
	Contact Tip (AgW Carbide)	18402-004	2	2	60	Auxiliary Contact Block	67976-001	1	1
16	Arc Transfer Tip	59465-002	1	1	61	Double Auxiliary Contact Assembly Kit (items 62 thru 64, 55, 57 thru 59 60 (two required))	68011-009	1	1
17	Moving Contact Holder	59458-006	1	1	62	Double Striker	68029-002	1	1
18	Contact Hinge Pin	59462-000	1	1	63	Sems Screw (6-32 x 1-1/2")	47661-088	2	2
19	Shunt	68027-001	1		64	Nut (6-32)	47253-012	2	2
	Shunt 5A	68027-002		1	65	Mechanical Interlock Assembly Kit (Consists of items 66 thru 73)	68041-016	1	1
20	Contact Spring	67981-030	1	1	66	Mounting Plate Assembly	59443-001	1	1
21	Armature Assembly	81279-050	1	1	67	Flat Washer (1/4")	47250-502	2	2
22	Armature Hinge Pin	18049-100	1	1	68	Collar	59447-000	1	1
23	Hair Pin Cotter	57403-005	2	2	69	Interlock Bar	68058-103	1	1
24	Core Cap	19657-000	1	1	70	Lockwasher (1/4")	47252-038	1	1
25	Non Magnetic Spacer	59545-000	1	1	71	Hex Nut (1/4-20)	47253-601	1	1
26	Coil Core	58720-001	1	1	72	Round Head Screw (8-32 x 0.375")	47776-063	2	2
27	Operating Coil 275V	67890-001	1	1	73	Flat Washer (#8)	47251-007	1	1
	Operating Coil 230/250V	67890-002			74	Tie Bar Kit (items 75 thru 79)	59400-005	1	1
	Operating Coil 115/125V	67890-003			75	Round Head Screw (8-32 x 0.875")	47241-106	4	4
	Operating Coil 75V	67890-004			76	Lockwasher (# 8)	47252-006	4	4
	Operating Coil 57.5V	67890-005			77	Washer (# 8)	47251-016	4	4
	Operating Coil 24V	67890-006			78	Spacer	41259-000	4	4
	Operating Coil 36V	67890-007			79	Tie bar	41131-002	1	1
	Operating Coil 12V	67890-008			80	Low Head SHCS 3/8-16 X .75	47100-505	1	1
	Operating Coil 440/460V	67890-009							
	Operating Coil 500/550V	67890-010							
28	Stator Assembly	19661-002	1	1					
29	Upper Terminal Assembly	68026-000	1	1					
30	Lower Terminal Bus	68024-000	1	1					
31	Stud Brass (1/2-13 x 1.93")	66475-021	1	1					
32	Hex Head Screw (3/8-16 x .75")	47246-012	3	3					
33	Split Lockwasher (5/16")	47252-039	9	9					
34	Hex Head Screw SS (5/16-18 x 1.5")	47779-083	1	1					
35	Split Lockwasher (1/4")	47252-038	1	1					
36	Hex Head Screw (1/4-20 x 1.5")	47246-069	1	1					
37	Flat Washer (5/16")	47250-514	1	1					
38	Split Lockwasher (3/8")	47252-040	8	8					
39	Hex Head Screw SS (5/16-18 x 1")	47779-081	1	1					



TROUBLE SHOOTING

TROUBLE	POSSIBLE CAUSE	SOLUTION
Contacts will not operate or operation is sluggish.	<ol style="list-style-type: none"> 1. Improper or defective operating coil. 2. Low control circuit voltage. 3. Loose connection in control circuit. 4. Mechanical interference or binding. 	<ol style="list-style-type: none"> 1. Check coil part number resistance to determine if coil is defective. 2. Check that control circuit voltage is a minimum of 80% of rated coil voltage. If it is zero, the problem is elsewhere in the circuit. 3. Check connections and tighten if loose. 4. Check for mechanical interference or bindings: <ol style="list-style-type: none"> 4a. Check mechanical interlock interference. 4b. Manually close the contact arm; check that the armature hinge pins are not binding. 4c. Manually close the contactor; check that the armature bearings are not binding.
Contacts will not open.	<ol style="list-style-type: none"> 1. Core cap spacer damaged or missing. 	<ol style="list-style-type: none"> 1. Inspect core cap spacer.
Contact tips overheating, short contact tip life.	<ol style="list-style-type: none"> 1. Loose connections. 2. Movable or stationary contact tip not properly aligned 3. Foreign matter on contact surfaces. 4. Contact tips worn beyond recommended limits. 5. Contact surfaces severely scored or burned 6. Arc shield not properly installed 7. Normal load currents below 5% of rated current of contactor. 8. Excessive current. 	<ol style="list-style-type: none"> 1. Check contact tips and shunt connections and tighten if loose. 2. Align contact tips by the procedure listed in the ADJUSTMENT-Contact Tip Alignment instructions in this Service Bulletin. Check for positive contact pressure from spring (31). 3. Remove foreign matter. 4. Check for contact war by the procedure listing in the MAINTENANCE-Contact Tip Replacement instructions in this Service Bulletin. 5. Inspect contact surfaces and dress with a file as required. 6. Check that arc shield is pivoted to the fully down position. 7. Use a smaller size contactor to improve blowout action. 8. Check that load currents are within contactor rating.
Operating Coil Overheats.	<ol style="list-style-type: none"> 1. Improper or defective 2. High voltage condition on coil. 3. Loose connection at coil terminals. 	<ol style="list-style-type: none"> 1. Check coil part number and resistance to determine if coil is defective. 2. Check that control circuit voltage does not exceed 110% of rated coil voltage for extended periods. 3. Check connection and tighten if loose.

Hubbell Industrial Controls, Inc.

a subsidiary of Hubbell Incorporated

4301 Cheyenne Dr., Archdale, NC 27263

Telephone (336) 434-2800 • FAX (336) 434-2803

<http://www.hubbell-icd.com>

Sales@hubbell-icd.com