



3- Product identification and matching transmitters / receivers

3.1- UCE transmitters

Transmitters are delivered with a **single battery pack** (a second can be ordered separately with the reference: **UWB**) and **without electronic key**, this one being delivered with the receiver (or can be ordered separately with the reference **UCWE22X**).

Button configuration description	Transmitter reference
Transmitter UCE with : 6 two-step pushbuttons (double speed). + 1 "On/Horn" button + 1 stop palmswitch button <i>delivered with :</i> 1 battery pack (ref. UWB) + 1 label kit "movements" (ref. UWE201)	UCE22220 

Button configuration description	Transmitter reference
Transmitter UCE with : 6 two-step pushbuttons (double speed) + 1 one-step pushbutton (single speed) + 1 electronic switch with 3 positions + 1 "On/Horn" button + 1 stop palmswitch button <i>delivered with :</i> 1 battery pack (ref. UWB) + 1 label kit "movements" (ref. UWE201) + 1 label kit "special functions nb.1" (ref. UWE204)	UCE2222DC 

Button configuration description	Transmitter reference
Transmitter UCE with : 8 two-step pushbuttons (double speed) + 1 "On/Horn" button + 1 stop palmswitch button <i>livré avec :</i> 1 battery pack (ref. UWB) + 1 label kit "movements" (ref. UWE201) + 1 label kit "special functions nb.1" (ref. UWE204)	UCE22222C 