

Монтаж зажимов безопасности SPANNFIX

Монтаж фитингов для шлангов с креплениями SPANNFIX осуществляется просто и быстро с помощью стандартных инструментов (см. иллюстрации). На предыдущей странице в колонке "OD" указан максимально и минимально допустимый внешний диаметр шланга при вмонтированном в него штуцере. Крепления SPANNFIX подходят для всех шлангов ELAFLEX, находящихся в пределах указанных размеров. SPANNFIX монтируются также со шлангами других фирм, если их качество и размеры совпадают с размерами и качеством шлангов ELAFLEX. За счет ребристой внутренней поверхности SPANNFIX достигается более плотный и надежный зажим шланга. Поэтому у шлангов с толстыми стенками при зажиме края попадают в углубления в креплениях, не мешая монтажу.

ВНИМАНИЕ: рабочий-монтажник несет ответственность и сам проводит испытание шланга на электропроводимость.

ДЕМОНТАЖ: следуйте действиям, проиллюстрированным 3 - 6 ниже, в обратном порядке. Штифт не может быть удален без применения тисков.

Assembly of SPANNFIX Safety Clamps

The assembly of SPANNFIX safety clamps is an easy operation and can be done quickly and safely with the correct tools (see pictures). Please see the column marked "OD" on the reverse of this sheet, this shows the minimum and maximum outer diameter of the hose (with the hose tail fitted) that the various types of SPANNFIX safety clamps can safely be assembled to.

SPANNFIX safety clamps can be assembled to all ELAFLEX hoses within the indicated hose diameters. They can also be used with other manufacturer's hoses that meet the same dimensional and construction standards. The SPANNFIX safety clamp has been designed to meet the modern day demand for hoses of braided reinforcement and thin wall construction. We are able to offer a larger hose "OD" range due to our design of gripping rings on the inner wall of the SPANNFIX safety clamp. This design is different from similar clamps that have smooth inner walls that can allow a hose to slip under pressure from the vice.

Please note: The assembler is responsible for testing the electrical continuity of the hose assembly.

When disassembling please see illustration 3-6 in reverse. Note the pin cannot be removed without using a vice.

SPANNFIX NR non reusable

The SPANNFIX NR safety clamp is mainly used for high pressure hoses. The locking pin does not have a head, therefore the pin can be driven into the locking rings and cannot be removed, it is recommended to "burn" the hole after assembly. The assembly of the SPANNFIX NR safety clamp is the same as described previously.

