IDEC

## **HE2B Series Redundant (Double) Basic Enabling Switch**

#### **HE2B Key features include:**

- 3 position funtionality (OFF ON –OFF) as required for manual robotic control
- Ideally suited for use as enabling (aka "deadman") switch on teach pendants
- Provides a high level of safety based on human behavioral studies that determine personnel may squeeze OR let go when presented with a panic situation
- Snap acting contacts from Off→On (1→ 2)
- Positive action contacts from On $\rightarrow$ Off (2 $\rightarrow$ 3) ensure no contact welding (per EN60947-5-1 / IEC60947-5-1)
- Contacts will not re-close when released from Off $\rightarrow$ On (3 $\rightarrow$ 1) (per IEC60204-1; 9.2.5.8)
- · Multiple contacts for enhanced reliability
- Monitoring contacts in addition to main load contacts
- Available with or without rubber cover (cover provides IP65 watertight seal)

















#### Specifications

Specifications				
Conforming to Standards		IEC60947-5-1, EN60947-5-1, JIS C8201-5-1, UL508, CSA C22.2 No 14		
Application Standards		ISO12100/EN292, IEC60204-1/EN60204-1, ISO11161/prEN11161, ISO10218/ EN775, ANSI/RIA R15.06		
Operating Temperature		-25 to +60°C (no freezing)		
Operating Humidity		45 to 85% RH (no condensation)		
Storage Tem	perature	-40 to +80°C (no freezing)		
Pollution Degree		2 (inside of panel/contact side)		
		3 (outside of panel/operating side)		
Contact Resistance		50mΩ maximum		
Insulation Resistance		Between live and dead metal parts: $100M\Omega$ maximum		
		Between positive and negative live parts: $100 M\Omega\mbox{ minimum}$		
Impulse With	stand Voltage	2.5kV		
Operating Frequency		1200 operations/hour		
Mechanical Life		Position $1 \rightarrow 2$ : 1,000,000 operations minimum Position $1 \rightarrow 2 \rightarrow 3 \rightarrow 1$ : 100,000 operations minimum		
Electrical Lif	e	100,000 (at full rated load)		
Shock	Operating Extremes	100m/s <sup>2</sup> (10 G)		
Resistance	Damage Limits	1000m/s <sup>2</sup> (100 G)		
Vibration	Operating Extremes	5 to 55Hz, amplitude 0.5mm minimum		
Resistance	Damage Limits	16.7Hz, amplitude 1.5mm minimum		
Terminal		0.110" quick connect / solder terminal		
Recommend	Wire Size	0.5mm² maximum / 1 line (20AWG)		
Solder Heat l	Resistance	260°C / 3 seconds maximum		
Terminal Pul	ling Strength	20N minimum		
Recommend	ed Screw Torque	0.5 to 0.8Nm		
Degree of Protection		with rubber cover: IP65, without rubber cover: IP40 (IEC 60529),		
Conditional Short-Circuit Current		50A (250V)		
Recommended Short Circuit Protection		250V/10A fast blow fuse (IEC 60127-1)		
Weight		Approx. 26g (without cover), 30g (with cover)		
Circuit Opening Force		60N minimum (button return monitor & button push monitor)		
Actuating Force (Operating)		500N minimum		

# **Ordering Information**

**HE2B - M 2 0 0 P Y** 

3 Position Switch 2: 2 contacts

(DPDT)

None: without cover Y: Yellow

B: Black **Rubber Cover** None: without

**Rubber Cover** 

Color

cover P: with cover

**Push Monitor Return Monitor** Switch Switch 0: None

0: None 1: 1 contact

1: 1 contact 2: 2 contacts

2: 2 contacts

USA: 800-262-IDEC Canada: 888-317-IDEC



#### **Part Numbers**

Model			Number of Contacts			Part Number	
		3 Position Switch	Push Monitor Switch	Return Monitor Switch	ratt Number		
	Without Rubber Cover		2	0	0	HE2B-M200	
1 1 1 1 1 1			2	1	1	HE2B-M211	
			2	2	2	HE2B-M222	
	With Rubber Cover	Yellow	2	0	0	HE2B-M200PY	
			2	1	1	HE2B-M211PY	
The second secon			2	2	2	HE2B-M222PY	
AT NOT CT   11 -0 12   22 M2 -0 2		Black	2	0	0	HE2B-M200PB	
8.00			2	1	1	HE2B-M211PB	
			2	2	2	HE2B-M222PB	

### **Ratings**


#### **Contact Ratings**


ontaot natings							
Rated Insulation Volute (Ui)					250V		
Thermal Current (Ith)				3A			
Rated Operating Voltage (Ue)			30V	125V	250V		
	3 Position Switch		AC	Resistive Load (AC-12	) –	1A	0.5A
		osition		Inductive Load (AC-15	) –	0.7A	0.5A
		witch	DO	Resistive Load (DC-12	) 1A	0.2A	_
Rated Operating			DC	Inductive Load (DC-13	0.7A	0.1A	-
Current (le)	Push/return Monitor Switch (NC Contacts)		AC	Resistive Load (AC-12	) –	2A	1A
				Inductive Load (AC-15	) –	1A	0.5A
			DC	Resistive Load (DC-12	) 2A	0.4A	0.2A
				Inductive Load (DC-13	) 1A	0.22A	0.1A
Contact Structure		3 Position Switch		2 co	2 contacts (DPDT)		
		Button Return Monitor Switch		0 to 2 contacts			
		Button Push Monitor Switch		0 t	0 to 2 contacts		

Minimum applicable load (reference) = AC/DC3V • 5mA (for reference only)

### **Circuit Diagrams Terminal Circuit Diagrams (bottom view)**

Printed Side NC1 NO1 C1 C2 NO2 NC2 HE2B-M200






IDEC

## **Operating Characteristics**


#### Operating Characteristics (without rubber cover/center of button being pushed)






Using rubber cover will change the operating load because the operating temperature would increase


#### Dimensions (mm) Without Rubber Cover



### With Rubber Cover



## **Mounting Hole Layout**



#### Accessories Replacement Rubber Cover

Apperance	Color	Part Number	Material
	Yellow	HE9Z-D2Y	Silicon Rubber
	Black	HE9Z-D2B	Silicui nubbei

IDEC


## **General Information**

#### **Safety Precautions**

- In order to avoid electric shock or fire, turn power off before installation, removal, wire connection, maintenance or inspection of switch.
- Follow specification when installing. Improper electrical load may damage switch, cause electric shock, or fire.
- Use proper wire diameter to meet voltage and current requirements. Using improper wires or incomplete soldering may cause fire due to abnormal heat generation.

## Installation Precautions HE2B

M3 nut is inside the rubber cover.




#### HE2B/HE3B

 A change in internal air pressure may cause the rubber boot to expand and shrink on an enabling switch that has the rubber boot sealed. This may affect the performance of the switch. Periodically check to ensure that the enabling switch is operating correctly.  If the panel is not level when mounting an enabling switch, the waterproof feature cannot be guaranteed.

#### HE3B

- The rubber boot has a tab to be used for orientation. When making a positioning hole in a panel, do not make a hole in the rubber boot, or the waterproof
  feature cannot be guaranteed. When the positioning hole is not on the panel,
  remove the tab, but do not make a hole in the rubber boot.
- When tightening the locking ring, secure the flange to prevent the enabling switch from rotating. In applications where the enabling switch is to be rotated, mount the switch in a recess on the panel as shown.




## Wiring Precautions HE1B/HE2B/HE3B

- Applicable wire size is 0.5mm² (20AWG) (maximum) / 1 line.
- When soldering the terminal, solder at a temperature of 260°C within 3 seconds. Use non-corrosive liquid rosin as soldering flux.

#### HE1G


• Wire Stripping Information

Wire Length		Terminal Number 1-4	Terminal Number 5-8	
L1, L2 (mm)		L1=40mm	L2=27mm	
L3 (mm)		L3=6mm		
13	11 0 0			



• Applicable Wire Size: 0.14 to 1.5mm<sup>2</sup> (24 - 16AWG, one wire per terminal)

#### Recommended Torque



	See Drawing Above	Recommended Torque
Rubber Boot & Base	А	1.2±0.1Nm
Connector & Grip Switch	В	4.0±0.3Nm
Connector	С	4.0±0.3Nm
Terminal Screw	D	0.5±0.6Nm
Do Not Remove	Е	

## Use Precautions HE2B/HE3B/HE1G

 To ensure the highest level of reliability connect both contacts to a monitoring device such as a safety relay.

#### HE1B/HE2B/HE3B

When installing the enabling switch ensure that it cannot be accidently
activated. For example, a protrusion from a teaching pendant could cause the
enabling switch to be activated by the weight of the teaching pendant.